



Service Note
THE PRODUCT DOES NOT SWITCH ON
PRODOTTO NON SI ACCENDE

Defect: Hood does not switch on

Difetto: La cappa non si accende

Valid for all hoods with this connection


Valido per tutte le cappa con questa connessione

1st CHECK: ENGINE RUNS OR IS SHORT-CIRCUITED

1° VERIFICA: MOTORE FUNZIONA O E' IN CORTO CIRCUITO

- Check motor operation
- Verificare funzionamento motore

5.
4.
3.
2.
1.




BLU/ BLUE } NEUTRAL
ROSSO/ RED }
GRIGIO/ GREY } SPEEDS
BIANCO/ WHITE }
NERO/ BLACK }

2ND CHECK: THREE-SPEED LINKAGE

2° VERIFICA: COLLEGAMENTO TRE VELOCITA'

5.
4.
3.
2.
1.



BLU/ BLUE } NEUTRAL
ROSSO/ RED }
NERO/ BLACK } SPEEDS
BIANCO/ WHITE }
NON COLLEGATO/ NOT CONNECTED }

Measurement of Ω (OHM) values between BLUE and other colours.

Misurazione valori Ω (OHM) tra il BLU e gli altri colori.

If an infinite OHMICO value occurs, it means that the motor is short-circuited, therefore the MOTOR and the ECB board must be replaced.

Se si verifica un valore OHMICO infinito significa che il motore è in corto, pertanto è necessario sostituire il MOTORE e la scheda ECB.

An aerial view of a city skyline, likely New York City, with a prominent geometric overlay of semi-transparent triangles in shades of red and blue. The Empire State Building is visible in the center. The text 'elica' is centered in the upper half of the image.

 elica

MetLife

WORLDWIDE